



## Congratulations on choosing a Warmfloor Heating System

You may visit [www.warmfloornz.com](http://www.warmfloornz.com) to download operating instructions and to view common questions and answers to help you understand the operation of your thermostat.

### OPERATING YOUR THERMOSTAT


Programming should have been completed before using this guide (by your installer.)



# Programmable Electronic Heating Thermostat Owners Operating Instructions Sheet

Code: WF TH1

For more information or for Warmfloor technical support, please visit  
**Visit [www.warmfloornz.com](http://www.warmfloornz.com)**



#### Manual Mode:

Turn Power on.

Press MODE button to select Manual icon symbol will appear.

Press ▲ or ▼ arrows to set the desired temperature

Press return

With manual mode your floor will maintain its temperature for a 24 hour period.

#### Automatic Mode:

Turn Power on.

Press MODE Button to select Automatic icon symbol will appear. With automatic mode your floor will maintain its temperature according to the heating periods your installer has programmed.

Note: While floor is heating, the icon appears at bottom left screen.

#### Programme Day and Time

(WITH THERMOSTAT TURNED ON)

1. Press DAY and view displayed day. Press ▲ or ▼ arrows to set the day
2. Press HOUR and view current hour. Press ▲ or ▼ arrows to set the hour
3. Press MIN and view current minutes. Press ▲ or ▼ arrows to set the minutes

#### To turn off heating system:

Press power button . The OFF icon will appear.